

Electric water kettle



Hiluxe 2 C/B/S

Instruction manual

EN



Hiluxe 2 C/B/S

The intended use of the device

The appliance is designed exclusively for cooking and heating drinking, clean (non-saturated) water, in the indoor environment, to the extent that is determined by technical and operational parameters and functions, safety and user instructions and external influences of the operating environment.

ORAVA electrical appliances are manufactured according to the state of the art and recognized safety-technical rules. Nevertheless, the use or use contrary to designation may result in the risk of injury or endanger the life of the user or third person, damage to the device and other material values.

1. GENERAL SAFETY INSTRUCTIONS AND WARNINGS

- This document contains important safety instructions and warnings for safe, correct and economical operation of the electrical equipment. Its compliance helps the user avoid risks, increase reliability and product life.
- In this document, the general term product is used in text parts such as: electrical equipment - any device used for the production, conversion, transmission, distribution or use of electricity.
- From the point of view of the purpose of using electricity, the concept of electrical equipment in the strict sense of the word will include the following categories:
 - household electric appliances,
 - information and communication equipment,
 - consumer electronics,
 - lighting equipment,
 - electrical and electronic tools,
 - toys and equipment for sporting and recreational purposes,
 - medical devices (aids),
 - monitoring and control devices,
 - vending machines.

1.1 General safety instructions

- Before operating the unit, we recommend that you carefully read the instruction manual and operate the equipment in accordance with the instructions!
- The safety instructions and warnings in this manual do not cover all the possible conditions and situations that may arise when using the device. The user must understand that a factor that cannot be incorporated into any of the products is personal responsibility and caution. These factors must therefore be ensured by users serving this device.
- Failure to follow the safety instructions and warnings is forbidden by the manufacturer for any damage to health or property!
- Keep the instruction manual as close to the device as possible throughout its service life. Always keep the instruction manual together with the appliance for future use and use by new users.
- Use the appliance only for the intended purpose and in the manner specified by the manufacturer.
- The appliance is intended for home and similar indoor use without special focus.
- This appliance is intended, in addition to domestic use, for the following uses:
 - in shops, offices and other similar work environments;
 - in economic buildings;
 - in hotels, motels and other residential environments;
 - in bed and breakfast establishments.
- It is not a professional device for commercial use.
- Do not change the technical parameters and features of the device by unauthorized modification or modification of any part of the device.
- The manufacturer is not responsible for damages caused during transportation, misuse, damage or destruction of the equipment due to adverse weather conditions.

1.2 Safety of the operating environment

- Do not use the device in an industrial environment or outside environment!
- Do not expose the appliance to:
 - sources of excessive heat or open flame,
 - dripping or splashing water,
 - vibration and excessive mechanical stress,
 - insects, animals and plants,
 - aggressive and chemical substances.
- The operating environment of the device must always be in accordance with the basic characteristics set out.

- Features of the operating environment:
 1. Ambient temperature: $+5 \div +40 \text{ }^{\circ}\text{C}$
 2. Humidity: $5 \div 85\%$
 3. Altitude: $\leq 2\,000 \text{ m}$
 4. Occurrence of water: intermittent condensation of water or occurrence of water vapor
 5. Occurrence of foreign bodies: quantity and type of dust are insignificant
 6. Protection degree: min. IP20 (device protected from touching dangerous parts by hand and non-waterproof)
- This degree of protection is not indicated on the product and on the technical parameters in the operating instructions.
- If the protection class of the product is different from IPX0, this information is then displayed on the label of the appliance or in the technical data of the operating instructions.
- Other characteristics of the domestic operating environment (mechanical stress - vibrations and vibrations, occurrence of plant, animals, weather effects ...) are negligible in terms of effect on the correct and safe use of electrical equipment.

1.3 Electrical safety

- Before connecting the appliance to the power supply for the first time, make sure that the voltage on the appliance label corresponds to that of the household electrical outlet.
- The electric appliance is designed to power from $1 / N / PE \sim 230 \text{ V } 50 \text{ Hz}$.
- The electrical safety of the appliance is guaranteed only if it is properly connected to the mains.
- Electrical protection class I equipment is equipped with a protection against electric shock by means of protective earthing of inanimate parts, which can become dangerous when the device is malfunctioning. Always connect such devices to properly installed mains sockets that are equipped with earthing conductors and have a properly grounded earthing conductor.
All electrical equipment is equipped with a three-wire power supply.
- Class II electrical equipment is protected against electric shock by double insulation or by enhanced insulation of hazardous live electrical parts. Device of protection class II it must not be equipped with means to connect protective earthing.
All electrical equipment is equipped with two-wire power supply.
- Class III electrical equipment is a device that is powered by a small safe voltage source (battery or accumulator) and does not present any danger to the user from electrical shock.

- In order to provide increased safety against the risk of electric shock due to the use of electrical appliances by laypersons, it is recommended to install the power supply circuit for sockets with a rated current not exceeding 20 A RCD with a rated operating current not exceeding 30 mA.

To ensure the safety and correctness of the electrical installation, consult a qualified electrician.

- Only use a power cord with a plug (mains lead) supplied with the device and compatible with a wall socket. Using another cable may result in fire or electric shock.
- Always connect an electrical appliance to an easily accessible mains socket. In the event of an operating fault, the appliance must be switched off as soon as possible and disconnected from mains supply.
- The power cord and mains plug must always be easily accessible for safe disconnection of the electrical appliance from the power supply.
- Do not pull off the power cord by pulling the cable. Disconnect the power cord by pulling the plug behind the power cord plug.
- If you use an extension cord, make sure that the total rated power of all devices connected to the extension cord does not exceed the max. current load on the extension cable.
- If you need to use an extension cord or power supply block, make sure that the extension cord or power pack is plugged into a power socket, and not to another extension cord or power supply. The extension power cord or power supply block must be designed for grounded electrical plugs and connected to a properly grounded electrical socket.
- The power plug of the appliance must be compatible with the mains socket. Never use any adapters or modify the socket in any other way. Do not use inappropriate or damaged drawers!
- To avoid electrical shock, plug the power cables into properly grounded electrical sockets. If the device is equipped with a 3-pole plug, do not use adapters that do not have a grounding element or remove the grounding element from the plug or adapter.
- Do not bend, crush or otherwise expose the power cord of the appliance to mechanical stress or external heat sources. Damage to the power cord may result in electric shock.
- When the power cord is damaged, disconnect the appliance from the mains and do not use it again.
- If the power cord is damaged, it must be replaced by the manufacturer, its service department or a similarly qualified person to avoid the risk of electric shock.
- Regularly check and maintain the electrical appliance as well as the power cord and power socket. Disconnect the power plug regularly and clean it if necessary. Pollution by dust or other substances may cause disruption of the insulating state and consequently fire.

- Do not expose the appliance to water or moisture. The ingress of water into the appliance increases the risk of electric shock.
If the power cord is wet or the water has penetrated the water, disconnect it immediately from the mains. If the appliance is plugged into a mains socket and if possible, turn off the power circuit before attempting
unplug the power. If you are pulling wet wires from a live power source, be very careful.
- If the electrical equipment is installed (connecting) the protective covers are dismantled, the electrical parts must not be accessible to the user when the installation is finished.

1.4 Safety of persons

- This appliance is intended for use and operation by persons without electrotechnical qualification - lay people, according to the instructions specified by the manufacturer.
- Device operation includes activities such as switching on and off, user manipulation and setting of operating parameters, visual or auditory inspection of the equipment, and user cleaning and maintenance.
- This appliance can be used by children under the age of 8 and persons with reduced physical, sensory or mental capabilities or lack of experience or knowledge when supervised or instructed to use the appliance safely and understand the dangers involved.
- Children may not play with the appliance.
- Cleaning and maintenance for users may not be performed by children unattended.
- Always keep the appliance out of reach of children during use and operation. Be sure to download the appliance even for a freely accessible power cord.
- Always be careful when operating the electric appliance! Do not use an electric appliance if you are overly tired, under the influence of medication or narcotic drugs that reduce attention and focus.
- Inattention during operation may result in serious injury.

1.5 Cleaning, maintenance and repairs

- Observe the normal user cleaning and maintenance of the appliance in the recommended way. Do not use solvents or harsh cleaners for cleaning. Pollution and visible stains from finger contact, respectively. The hands can be cleaned using detergent detergents specially designed to clean household appliances.
- If you do not use the appliance, clean it or disconnect the appliance from the power supply when the appliance is faulty.
- Electrical appliances that are cleaned after use and are not intended to be completely or partly immersed in water or other liquid, protect against the effects of dripping and / or splashing water and before immersion.
- Electric household appliances, like all other technical devices, are subject to the surrounding environment and natural wear. Since the legal framework of regular maintenance is not laid down for lay-in electrical household appliances, the manufacturer recommends that the user have the appliance checked and cleaned at least once a year by a specialist workshop.
- By doing so, it is possible to achieve safety, operational reliability and increased service life.
- Do not disassemble the electric appliance! The appliance works with a dangerous voltage. For this reason, always switch off the appliance and disconnect it from the mains supply during user maintenance. In the event of a fault, please have the repair serviced by an authorized service center.
- Before calling a service:
 1. Turn the appliance off and on to make sure the fault reappears.
 2. If the malfunction of the appliance still persists after these operations, call the nearest specialist service center.
- Never repair the electric appliance yourself!
- Unauthorized, unqualified and improper use of an electric appliance may result in electric shock or other serious injury.
- Only carry out the warranty or post-warranty repair of an electrical appliance to an authorized qualified person (*).

(*) Competent qualified expert: the sales department of the manufacturer or importer or the person qualified and authorized to carry out this type of activity with the ability to avoid all risks.

2. Special Safety Instructions.

Read carefully!

- Electrical equipment is designed and manufactured in such a way as to allow for safe operation and use by persons without a professional qualification. Despite all measures taken by the manufacturer for safe use and handling, they carry with them some residual risks and associated potential hazards.
- The following symbols and their meanings have been used on the device and in the accompanying documentation to warn of possible hazards:



This symbol alerts users that the device is operating a dangerous electrical voltage. Do not remove protective covers on the device. Failure to observe the safety instructions during use and operation of the device may result in: Danger of electric shock! Danger of serious injury or life threatening!



This symbol alerts users that the following precautions can be avoided if the following precautions are observed when operating and operating the device: Danger of serious injury or life threatening! Danger of damage to equipment or other damage to property!



This symbol alerts users to the following:
Disable the use of the device in a bathtub or shower.

Transport/Carriage

- When transporting and using, for example, of the transport cart, be careful when moving, to avoid overturning the device and damaging it.
- Transport / carry the equipment only after thorough inspection of the space and the routes, which must be unobstructed.
- Never carry the machine while it is in operation. Do not carry the device while it is plugged into a wall outlet.
- Transfer the device firmly to the handle and the bottom edge of the base or solid parts of the body.
- Make sure that your hands and equipment are not damp or slippery when carrying.
There is a risk of serious injury or life threatening!
There is a risk of damage to the device!

Unpacking/Packaging

- Unpack and remove all parts of packaging waste and labels before putting the device into operation. Keep all packaging materials in a safe place or keep them out of the reach of children and inappropriate persons.
There is a risk of serious injury! There is a risk of choking!

Check/Startup

- The appliance is designed for food preparation. Therefore, clean all parts before putting it into operation according to the instructions in section „Putting into operation“, respectively. „Cleaning and maintenance“.

Warning!

- Never immerse the kettle, the base (power stand), the power cord or its plug into water or other liquids.
- Never clean the device (kettle with base) and the power cord with the plug in a way that could cause the liquid to flow into the device. Clean these parts with a slightly moistened cloth and wipe dry or let it dry. Clean the device only when switched off is disconnected from mains power and sufficiently cooled.
- We recommend performing both initial and subsequent regular machine inspections. It is very important that the lid is well closed and not damaged. No curtains may be damaged. Do not attempt to interfere with the construction or adjustment of the component parts in any way.
- Never use the appliance if it is incomplete, damaged, or any part of it has been damaged during use. If the device is damaged, have it repaired by a specialist service.
- Do not use the non-original and incomplete parts of the appliance - the kettle and the appropriate base (power stand) with the power cord and the plug.

There is a risk of electric shock!

There is a risk of serious injury or life threatening! There is a risk of damage to equipment or other property damage!

Location/Installation

- Use the device only in places where it is not overturned.
- Only place the appliance on straight, firm and stable pads - kitchen work desks and furniture parts, suitable for the location of kitchen utensils.
- Always make sure that the place you want to place the device has enough space, stability, mechanical strength and adequate lighting.

Warning!

Do not dispose of the device:

- unstable tables or inappropriate parts of furniture,
- on an uneven and dirty surface,
- on the sealing edge of tables or parts of furniture,
- in the vicinity of containers with water or other liquids.

Do not expose the device to:

- direct sunlight, sources and equipment producing heat,
- vibration and mechanical stress,
- excessive dust,
- insect,
- aggressive effects of the external environment.

- Do not cover the appliance at all. Do not place any objects on the device. Do not insert or allow the foreign bodies to enter the holes of the device covers.
- Do not cover the openings of the airflow covers. Air ventilation ensures reliable and safe operation of the device. There is a risk of very serious injury!
There is a danger of fire!

Warning!

- Place the device in a place where children can not reach freely. Work desks and furniture for placing should not be lower than 85 cm.
- Prevent children from playing with the device. The device may overturn and cause very serious injury. Mechanical damage (breakage or breakage of parts and covers) of the device can cause serious injury.
There is a risk of very serious injury!
There is a risk of damage to equipment or other property damage!
- Do not place or use the appliance in the vicinity of bathtubs, showers, washbasins or other containers containing water, including the pool. If the appliance falls into the water, do not remove it! First, pull out the power cord plug from the power outlet and then the device
choose from water. In such cases, take the device for inspection to a specialist service to check that it is safe and working properly. There is a risk of electric shock! There is a risk of electrical short circuit!

Operation/Supervision

Warning!

- When heating water, a high degree of water heating (to boil) and hot steam generation occurs. Be very careful at the time of operation.
Vapor water and steam are very hot!
There is a risk of very serious injury!
There is a risk of burns from hot water and hot steam!
- Always keep your device under control during use and operation!
- This device is not intended to be operated via a programmer, external time switch or remote control because there is a risk of fire if the device is covered or incorrectly positioned.

- Do not use the device in potentially explosive environments in the presence of flammable substances and their vapors, mist or dust, and under atmospheric conditions, where the combustion air is easily propagated by air.

There is a risk of explosion and / or fire!

Caution!

- Do not use the appliance to heat or cook other types of liquids!
There is a risk of damage to the device!
- Make sure that the main switch is set to „OFF“ in the „0“ position before each connection to the mains.
- Do not switch the device on or off by plugging in or pulling out the plug of the power cord from the wall socket.
- Always connect the appliance to mains power supply for normal use, then turn on the main power switch.
- When you have finished using the appliance, turn off the main switch and then pull out the power cord plug from the mains socket.
- Do not use the device if the main power switch does not work on the device.
- Interruption of operation of the device can be done by turning the main switch off manually at any time during operation (during cooking / heating of water).
- Do not remove the kettle from the base until it has stopped automatically.
- The device is under dangerous voltage when the power supply is connected.
There is a risk of electric shock!

Caution!

- Do not turn on the appliance unless the kettle is filled with water.
- Never fill the kettle when it is placed on the base (stand) and connected to a wall outlet.
- Before turning on the appliance, make sure that the water level in the kettle corresponds to the specified cooking / heating volume range from MIN to MAX.

- If the kettle is overflowing, hot water may be leaking or splashing.
Excess water can burn electrical parts of the device.
There is a risk of electrical short circuit!
There is a risk of electric shock!
- Make sure the lid of the kettle is properly closed before switching on the appliance.
- Do not open the lid until the water is removed and the appliance is not automatically turned off.
- Do not open lid when spilling residual water after cooking / heating.
- Do not get close (close to your hands, face ...) near the sink spout while the appliance is operating.

Warning!

- The device contains parts and surfaces which are greatly heated during operation - surface areas, the lid and the metal bottom of the cooking vessel.
- Do not touch hot surfaces and parts! Only use a handle designed to handle the device at the time of operation!
- Open the lid of the machine while it is running (after cooking) to open slowly and carefully. When suddenly opening, hot steam escapes from the working area of the appliance.
- Never pull inside the kettle unless the device is cold enough.
- Do not touch the metal bottom of the kettle until it is completely cold.
There is a risk of burning from the hot surface! There is a risk of burns (hotplates) from hot water and hot steam!

Caution!

- After turning off the machine, the surfaces remain warm for a certain amount of time. Before any further handling of the device – cleaning and storage, always wait until the device cools down completely.
- The electrical socket and power cord must remain easily accessible for safe disconnection of the appliance from the power supply.

- Never leave the appliance unattended and freely accessible with a free-hanging power cord. Children, inappropriate persons or animals could download the device for the power cord. Store the device with wrapped cord around the base.
There is a risk of serious injury!
- Never overload the equipment beyond the limits specified by the technical specifications!
- Observe the operating mode of the machine in accordance with the operating instructions.
- Do not expose the kettle to heat shock - do not add ice water to the hot kettle.
- Fill the kettle if it is cold enough and only with drinking, clean and cold water.
- If you notice any unusual occurrences (sounds, odors, smoke, etc.) during use of the device, switch off the device immediately and disconnect it from the power supply. Have the appliance checked by a specialist workshop.
- Keep the body of the kettle and the base (power stand) with the power cord clean.
- Do not remove the water filter while the kettle is running hot water. When taking the water filter, be very careful.
- Regularly inspect and clean the interior of the kettle - dispose of calcium deposits. Follow the instructions and procedure in „Removing calcium deposits“.
- Incorrect cleaning adversely affects the function and life of the device.
- If any safety component / component (mechanical, electrical) is part of the device, never disable this part / component! If the safety component / part is damaged or not working, do not use the appliance!
- Never underestimate the potential hazards and take extreme caution !!!

Operation

Description of parts and controls:



- 1 top cover
- 2 spout with strainer
- 3 stainless body
- 4 base with 360 ° rotation
- 5 0/I (on/off) switch with automatic switch off at the boiling point/
operation light
- 6 water level scale
- 7 handle
- 8 top cover open button

Preparation and operation

Unpack the device, check it for damage, and remove any packing material from the device.

Requirements for connection to the mains

- Before connecting the appliance to the mains, make sure that the mains voltage of the mains corresponds to the information on the rating plate located on the mains base and the base of the kettle.
- The device may only be connected to a 230 V ~, 50 Hz electrical socket.

Before using boiled water for the first time, you must first boil water 3 times in a kettle filled with potable water to the maximum level mark, pour it out and rinse the kettle thoroughly.

- 1 Unwind the power cord from the base. Place the machine on a flat and stable surface.
- 2 Fill the kettle with an adequate amount of water. Please observe the water level scale and the MIN indicator. and MAX. Close the lid, otherwise the kettle will not turn off automatically when the water is trapped and the water may boil out of the kettle.

Caution !

The water level must be between MAX. (1.7 l) and MIN. (0.5 l) on the scale. Too little water can cause damage to the heating element and too much water can cause water to run out during boiling.

- 3 Connect the base unit to the mains. Place the kettle on the power base. Place the kettle so that its mouth faces away from you. After placing the kettle on the base, the kettle is ready for operation.
- 4 To set the kettle in operation, set the 5 0/I switch to I (on).

WARNING!

Never fill the kettle while it is placed on the base. If the kettle is overfilled, boiling water may be splashed. Do not run the kettle suddenly. Improper use of the kettle can adversely affect its service life. If you accidentally turn on the kettle without water, the thermostat will automatically switch off the kettle when it reaches a certain temperature. Switch 5 is set to the 0 (off) position and the indicator light goes out.

SWITCHING OFF

To turn off the kettle before boiling water, turn the switch (5) to position 0 (off). Unplug the machine after use. Do not open the cover when pouring water

PROTECTION FROM HEATING WITHOUT WATER

If you accidentally turn on the kettle when it is empty, it will automatically turn it off without water.

Allow the kettle to cool for a short time or fill with water. After a short break you can use the kettle in the normal way.

Warning!

- Never use the device empty. If this happens, the thermal fuse will automatically shut down the device. Unplug the machine and let it cool completely.
- Do not touch the metal floor during operation. It may cause burns.

Care, maintenance and cleaning

- 1 Unplug the machine and allow it to cool completely before cleaning.
- 2 Do not immerse the power cord, kettle, or base in water.
- 3 For a smooth and shiny surface, do not use solvents or abrasive cleaners.

You can wipe the outside of the kettle with a damp cloth, then polish with a soft and dry cloth.

WARNING!

Never submerge the kettle, the power base, the power cord or its plug into the water!

MAKE SURE THAT THE BOTTOM SECTION, THE STAND, THE POWER CORD AND THE PLUG DO NOT CONTACT WITH MOISTURE!

- 4 Regular descaling is required. The cleaning interval depends on the hardness of the water in your area and the frequency of use of the kettle.

- 5 For easier storage, the power cord can be wrapped around the base at the bottom.
Ensure that the kettle is switched off, clean and dry before storing the kettle. Ensure that the lid is securely fitted in the closed position. Wrap the power cord around the holder at the bottom of the stand. Place the kettle vertically on the stand.
Do not place any objects on the kettle lid.
- 6 Do not disassemble! Have repairs carried out by an authorized service center.

Lime salt removal

Remove the scale in the interior of the kettle according to the frequency of use of the kettle.

When using the kettle normally (3 to 5 times a day), we recommend removing limescale:

- once a month in areas with hard and very hard water;
- once every two to three months in areas with soft and medium hard water.

Use diluted vinegar or citric acid lime salt remover for cleaning. Dispense and use the lime salt remover only as directed by the manufacturer.

Mineral deposits may cause undesirable discoloration of the interior of the kettle and watermark after a period of time. Remove these deposits with a special mineral removal agent available in most supermarkets or department stores.

Alternative procedure

- 1 Fill the kettle to 2/3 with a solution of one part vinegar and two parts of water, bring the solution to a boil and leave to stand for the next day.
- 2 Empty the kettle, fill it with clean water, bring the water to a boil and then pour out. Repeat this procedure until the kettle is clean and ready for use.

Technical specifications

Power supply:	220 - 240 V~ 50/60 Hz
Power input:	2 000 W
Capacity:	1,7 l
Dimensions (WxHxD):	22,5 x 23,5 x 14,5 cm
Weight:	0,9 kg

Producer:

ORAVA retail 1, a.s.
Seberínho 2
821 03 Bratislava
Slovenská republika

Importer:

ORAVA retail 1, a.s.
Seberínho 2
821 03 Bratislava
Slovenská republika

ORAVA distribution CZ, s.r.o.
Ostravská 494
739 25 Sviadnov
Česká republika

DISPOSAL OF USED ELECTRICAL AND ELECTRONIC EQUIPMENT



The symbol on the product or on its packaging indicates that this product does not belong to household waste. It is necessary to take it to a collection point for electrical recycling and electronic equipment.

By ensuring proper disposal of this product, you will help prevent negative consequences to the environment and human health that would otherwise be caused by inappropriate disposal of this product. For more detailed information about recycling of this product, please contact your local authority, your household waste disposal service or the shop where you purchased the product.



This product meets all the essential requirements of the EU directives that apply to it.